Firmware and lighthouse firmware upgrade

13.11.2026 09:24:30

Печать статьи FAQ

Категория:	PlayVR::Administrators (EN)	**Голоса:**	0
Состояние:	общедоступное (всем)	**Результат:**	0.00 %
Язык:	ru	**Последнее обновление:**	10:46:00, Втр 16 Июл, 2019 г.

Симптомы (общедоступное)

Проблема (общедоступное)

Решение (общедоступное)

Lighthouse Firmware Update with Cable Connection
- On your computer, open the SteamVR application.
- When the icon appears, hover over it. Check the latest firmware version. If the version is outdated, click Update Base Station Firmware.
- Disconnect base stations from power supplies. Carefully dismantle the base stations.
- Using a micro USB cable, connect the base stations alternately to one of the USB ports on your computer.
- Press and hold the "Channel" button on the back panel of the base station, at the same time connect the station power supply.

After the base station is detected by the SteamVR application, the firmware update will start automatically.

Warning: Do not disconnect the micro USB cable or power cable until the upgrade process is complete. This may cause a program error.
After the update is complete, click Finish.

Controller firmware update
- On your computer, open the SteamVR application.
- When the icon appears, hover over it to check for the latest firmware version. If the version is outdated, click Update controller firmware.
- Using a micro USB cable, connect the controllers in turn to one of the USB ports on your computer.

After the controller is detected by the SteamVR application, the firmware update will start automatically.

Warning: Do not disconnect the micro USB cable until the upgrade process is complete. This may cause a program error.

4. After the update is complete, click Finish.